



life.augmented

Hackathon Problem Statement – Synthetic Data Generator for Human Activities of Daily Living

Hem Dutt Dabral (SRA)

Agenda

Topic

Topic

Topic

Topic

Topic


Topic

Topic

Topic

- MEMS sensors can be used to collect motion data corresponding to human activities of daily living like walking, running, swimming, resting, yoga pose etc.
- ST hardware platforms like B-L475E-IOT01A and STEVAL-MKBOXPRO1 have 3D MEMS accelerometer and gyroscope sensors like LSM6DSL mounted on them
- Collecting real MEMS sensor data can be tricky, as it requires:
 - Access to HW platform which incurs logistical and financial cost
 - Physical setup has to be attached to a person's wrist, waist etc. which can be inconvenient
 - e.g. attaching the hardware kit to wrist using some physical arrangement
 - Knowhow about usage of data collection software like High-speed data logger (FP-SNS-DATALOG2), STAlotCraft etc.

AIoT Application development Cycle



- Data retrieved from MEMS acc/gyro sensors like LSM6DSL is consumed by training and inference phase of an AI application
- Data collection is time consuming and sometimes cumbersome phase of AIoT (Artificial Intelligence of Things) application development.
- A human subject must wear sensors correctly at right place (e.g. wrist, waist etc.)
- Large amount of data is required for training and testing AI model

Need for Generative AI based solution

- Generative AI has made it possible to generate artificial videos, images and audio samples
- We can leverage generative AI models to create sensor data for specific activities like running, walking, sitting etc.
- Such a system can be integrated with tools present in ST Edge AI suite (e.g. ST AIoT Craft) for rapid application development by researchers without requiring a hardware board
- Result: Enhanced customer experience and engagement with ST software ecosystem

Synthetic Data Generator For Human Activities of Daily Living

- Create a Generative AI model and helper scripts for generating 3D MEMS accelerometer data for Human Activities Recognition UC
 - Sensor: LSM6DSL
 - 3D accelerometer full scale range $\pm 2/\pm 4/\pm 8/\pm 16$ g meter per second square
 - Sample duration: specified using input configuration, 1-5 seconds
- Activities to be covered:
 - walking,
 - running,
 - stationary
 - cycling,
 - Nordic walking,
 - Ascending stairs,
 - descending stairs,
 - ironing,
 - house cleaning,
 - playing soccer,
 - rope jumping

I/O Constraints on Synthetic Data Generator

- Input format: system to be configured using a JSON input file



sample_configuration.json

```
1 - {
2 -   "activities": [
3 -     "walking",
4 -     "running",
5 -     "stationary"
6 -   ],
7 -   "samples_per_activity": 100,
8 -   "sample_duration_in_ms": 1000,
9 -   "acc_mg_range": {
10 -     "min": -4000,
11 -     "max": 4000
12 -   }
13 }
```

- Output data should be compatible with this dataset: [stm32ai-wiki/AI_resources/HAR/dataset at master · STMicroelectronics/stm32ai-wiki · GitHub](https://wiki.ai-resources/HAR/dataset-at-master-STMicroelectronics/stm32ai-wiki-GitHub)
 - Each generated sample should be saved to a CSV file, in a directory named as <activity_name>
 - Variable duration (1-5 seconds), 3 columns (along X, Y, Z directions)
 - Acceleration range: -4000 mg to +4000 mg
 - Sensor: LSM6DSL
 - Sampling rate: 26 Hz
- Publicly available datasets can be used for training AI model (e.g. WISDM, PAMAP2 etc.)

Acceptance Criterion

- Acceptance criterion:
 - Accuracy: A discriminative AI model will be used to classify the generated data.
 - At least 99.5% classification accuracy is required on generated samples
 - Originality: Use of existing AI models is not allowed
- Artifacts to be submitted
 - ML model in Keras compatible format (.keras, .h5)
 - Source code:
 - Model training/testing scripts
 - Supporting script for generating N synthetic samples saved to CSV files in given directory, using following command line
 - `python <script_name> --config <configuration.json> --out output_dir_name`

Sample Input Configuration File

```
{  
  "activities": ["walking", "running", "stationary"],  
  "sample_count_per_activity": 100,  
  "sample_duration_in_ms": 1000,  
  "acc_mg_range": {  
    "min": -4000,  
    "max": 4000  
  }  
}
```

Our technology starts with You



Find out more at www.st.com

© STMicroelectronics - All rights reserved.

ST logo is a trademark or a registered trademark of STMicroelectronics International NV or its affiliates in the EU and/or other countries.

For additional information about ST trademarks, please refer to www.st.com/trademarks.

All other product or service names are the property of their respective owners.



life.augmented